


CINEVISION

The new Postcard screen.



CINEVISION:
Lacing of the fabric with eyelets at the back of the frame. Round or square corners.



WALL MOUNT

The standard mounting is on the wall, with an adjustable gap between the screen and the wall.


Short wall mount

Long wall mount



Other mounting systems are available (suspended from the ceiling, mounted on feet, ...)

Quick suspension of the frame on its mounts and locking feature by 45° rotation of the junction part



SUSPENSION MOUNT

